


WiFi Sound&Flash Siren User Manual




Packing List

Please check if all accessories are included.



Appearance and Components

Product appearance




Product Features

1. Sound&flash alarm for 100 dB.
2. Anti-tamper design
3. Wireless communication, ease-of-installation
4. Fire proof material, ABS+PC

Power on and Network Setting

1. Power on the device, red LED is on for 3s, siren beeps "DI-DI".
2. Network access/exit: press volume button+and- together for 5-10s for network access or exit.




Note:
When receiving alarm signal from other device, redLED indicator will flash and buzzer beeps. To clear the alarm, please operate on App.

Main Function

1. Network setting: press volume button+and- together, red LED is on for 5s then off, release the button. Red LED flashes for network setting. If network succeeds, red LED is on for 5s then off; If fails, red LED is off directly.
2. Volume adjustment: When siren alarms, press + or - to adjust.
3. Anti-removal switch: When siren is removed from the installation base, siren will alarm.
4. Power on/off: Connect with power adapter, siren turns on. If only battery powered, press OFF/ON button for 5s to turn it on/off.
5. LED indicator
When power on: Red LED is on for 3s, buzzer beeps "DI-DI"
When networking: Red LED flashes
Network succeeds: Red LED is on for 5s then off.
Network timeout: Red LED is off after flashing.
Power off: Buzzer beeps "DI".


Installation Position and Precautions

1. Install indoor, such as on tile, wall, or painted wood.
2. Reinforced concrete materials will shorten the wireless communication distance.




Product Installation


1. Rotate the mounting base counterclockwise to remove it from the product.



2. Fix the mounting base on the wall with screws or 3M sticker, then install the siren to the base.
Clean the wall surface if using 3M sticker.



3. Connect the siren to the power adapter.



App Download

1.Search for “Smart Life” in APP Store or Google Play Store. Or, scan the below QR code to download the APP.



Scan to download
Smart Life APP

Network Setting

- 1. Power on the WiFi device;
- 2. Make sure the network indicator flash(if not, long press reset button until indicator flashes.)
- 3.On App homepage, click "+" on top right corner; Click "Security &Sensors" on the left side of the page, and select the right WiFi sensor type to add device;
- 4. If successfully added, device will be in “My home” list.

Technical Parameters

Wireless Technology	WiFi
Transmission Frequency	2.4GHz
Working Voltage	5V (power adapter)
Working Temperature	-10℃ ~ +55℃
Relative Humidity	<90%
Size	Φ80×35mm

Toxic or Hazardous Substances or
Elements of this Product

Component Name	Toxic or Hazardous Substances or Elements					
	Lead (Pb)	Mercury (Hg)	Cadmium (Cd)	Hexavalent chromium (Cr(VI))	Polybrominated biphenyls (PBBs)	Polybrominated diphenyl ethers (PBDEs)
LED	O	O	O	O	O	O
PCB	O	O	O	O	O	O
Cover and other components	O	O	O	O	O	O
<p>This table complies with SJ/T 11364.</p> <p>O: indicates that the toxic or hazardous substance amount contained in all homogeneous materials of a component does not exceed that stipulated in GB/T 26572.</p> <p>X: indicates that the toxic or hazardous substance amount contained in at least one of the homogeneous materials of a component exceeds that stipulated in GB/T 26572.</p>						



Warranty Certificate

Warranty policy:

- 1. If the product has quality problems within 7 days of the payment date, you can apply for a refund based on the invoice price or to replace with the same model or have it repaired.
- 2. If the product has quality problems within 15 days of the payment date, you can apply to replace the product with he same model or have it repaired.
- 3. If the product has quality problems within 12 months of the payment date, you can apply to have it repaired.

What is not covered under this warranty:

- 1. The product owner has no warranty certificate or the warranty service has expired.
- 2. Damage caused by improper use, maintenance, or storage
- 3. Damage caused by disassembly and repair without Tuya’s authorization
- 4. Damage caused by force majeure
- 5. Normal discoloration and depreciation after the product has been used

User Form

User information (Specify real information. Tuya promises to use the information only for after-sales services.)

Name _____

Phone number _____

Email _____

Zip code _____

Address _____

Product information

Name_____ Model _____

Color _____Product SN _____

Service ☐Return ☐ Replace ☐ Repair

Fault symptoms _____

Handling date_____

Maintenance personnel signature _____

Vendor Form

User information (Specify real information. Tuya promises to use the information only for after-sales services.)

Name _____

Phone number _____

Email _____

Zip code _____

Address _____

Product information

Name_____ Model _____

Color _____Product SN _____

Service ☐Return ☐ Replace ☐ Repair

Fault symptoms _____

Handling date_____

Maintenance personnel signature _____